

USING A BALL VALVE TO CONNECT A TANK TO A HOSE

A basic guide on how to use the water stored inside your tank.

ASSEMBLY

- 01** Screw **(B)** 40/25mm reducer into **(A)** 40mm water fitting (pre-fitted - supplied standard with tank).
- 02** Fit **(C)** 25mm barrel nipple into **(B)**.
- 03** Fit **(D)** ball valve onto **(C)**.
- 04** Fit **(E)** 25/20mm reducer onto **(D)** ball valve.
- 05** Fit **(F)** 20mm accessory onto **(E)**.

Note:


Connect a hose to the accessory adaptor **(E)** as required to use the water in your tank

Tip:


Use thread tape where required to ensure the connections are properly sealed to prevent water from leaking

COMPONENTS REQUIRED


A | 40mm Water Fitting




B | 40/25 Reducer




C | 25mm Barrel Nipple



D | 25mm Ball Valve



E | 25/20mm Reducer



F | 20mm Accessory Adaptor

