


Using a ball valve to connect a tank to a hose

A basic guide on how to use the water stored inside your tank




COMPONENTS REQUIRED




A. 40mm Water Fitting




B. 40/25 Reducer



C. 25mm Barrel Nipple



D. 25mm Ball Valve



E. 25/20mm Reducer



F. 20mm Accessory Adaptor

ASSEMBLY

01

Screw **(B)** 40/25mm reducer into **(A)** 40mm water fitting (pre-fitted - supplied standard with tank).

02

Fit **(C)** 25mm barrel nipple into **(B)**.

03

Fit **(D)** ball valve onto **(C)**.

04

Fit **(E)** 25/20mm reducer onto **(D)** ball valve.

05

Fit **(F)** 20mm accessory adaptor onto **(E)**.

Note: Connect a hose to the accessory adaptor (E) as required to use the water in your tank

Tip: Use thread tape where required to ensure the connections are properly sealed to prevent water from leaking