

# Tank Gauge

## WATER MONITORING MADE EASY

The Rain Harvesting Tank Gauge is a tank level indicator that ensures you are able to tell how much water is in your tank at a glance.

### FEATURES & BENEFITS



- Quick and easy to install - simple DIY product
- Seals directly to the tank
- Suitable for all existing and new tanks
- No batteries or wiring required
- Easy to read dial face with 'Empty' and 'Full' indicators
- Empty and Full indicators allow for a more meaningful measurement than a numbered dial (due to different rainwater tank widths and styles)
- Requires a standard 32mm hole saw
- Low maintenance requirements
- UV resistant
- Suitable for all vented tanks up to 2.5 meters (100 inches) in height
- Able to be securely installed on a wide variety of tank shapes (dome-topped, flat, peaked)
- Utilizes a reliable float system

### CALIBRATION

1. Carefully remove the front clear face from the Tank Gauge to enable access to the movable Empty and Full indicators
2. Select an installation site for the Tank Gauge and mark it. It is preferable that this is a flat area and that once installed, will allow you to view the Tank Gauge face easily
3. Whilst maintaining the same height and keeping the weight outside of the tank, extend the weight so it is level with the bottom of your tank. Move the red Empty indicator to where the water level indicator is pointing.
4. Lift the weight so it is level with the overflow on your tank and move the green Full indicator to where the water level indicator is pointing.
5. The Tank Gauge is now calibrated. Replace the front clear face.

### PRE-INSTALLATION

- Before installing your Tank Gauge it is important to calibrate it before use
- This will allow you to set your tanks Empty and Full positions and quickly see your tank's water level







**Rain Harvesting**

# Tank Gauge

## INSTALLATION

- Drill a 32mm hole into your tank at the previously marked installation sit.
- Lower the weight through this hole and sit the Tank Gauge on your tank.
- Using the supplied screws secure the Tank Gauge to your tank.
- Your Tank Gauge is now installed and ready for use.



*Note: all measurements in mm unless otherwise stated.*